





REPLACES	AUTOCAD	2309-2229	REV E
REVISION DATE 6-6-01	THE TRANE COMPANY A DIVISION OF AMERICAN STANDARD INC.	原理图 2 压缩机 中大 空气冷却 CKT 1 压缩机(1A) 星三角启动柜	
DRAWN BY PBL	THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED, REPRODUCED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS WITHOUT THE WRITTEN CONSENT OF THE TRANE COMPANY.		
DATE 10-25-00	SIMILAR TO		

CAUTION
USE COPPER CONDUCTORS ONLY!
UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT
OTHER TYPES OF CONDUCTORS.
FAILURE TO DO SO MAY CAUSE DAMAGE TO THE
EQUIPMENT.

注意
机连接端子未设置接受其它类型的导线,只能使用铜导线。
否则,会导致对设备的破坏。

警告
当心触电!
检修时应按照闭锁和开锁程序切断所有电源。
包括切断远程电源。
确保所有电动机电容器的存储电压已彻底释放。
对带可变速驱动装置的机组,应参照其驱动说明
释放电容器电压。
未接上地线定操作,将可能导致严重的人身伤亡。

WARNING
HAZARDOUS VOLTAGE!
DISCONNECT ALL ELECTRIC POWER
INCLUDING REMOTE DISCONNECTS
AND FOLLOW LOCK OUT AND TAG
PROCEDURES BEFORE SERVICING.
INSURE THAT ALL MOTOR
CAPACITORS ARE COMPLETELY CHARGED
STORED VOLTAGE UNITS WITH
VARIABLE SPEED DRIVE, REFER
TO DRIVE INSTRUCTIONS FOR
CAPACITOR DISCHARGE.
FAILURE TO DO THE ABOVE
BEFORE SERVICING COULD RESULT
IN DEATH OR SERIOUS INJURY.

- 27 —
- 28 —
- 29 —
- 30 —
- 31 —
- 32 —
- 33 —
- 34 —
- 35 —
- 36 —
- 37 —
- 38 —
- 39 —
- 40 —
- 41 —
- 42 —
- 43 —
- 44 —
- 45 —
- 46 —
- 47 —
- 48 —
- 49 —
- 50 —
- 51 —
- 52 —
- 53 —
- 54 —
- 55 —
- 56 —
- 57 —
- 58 —
- 59 —
- 60 —

