



变频挂机空调外机拨码控制器

使用说明书

获取更多资料 微信搜索蓝星地球

适用机型

厂家	机型	机型	机型
奥克斯	KFR-26GW/BpCC+2d	KFR-26GW/BpVD+3	KFR-35GW/BpLA+3
	KFR-26GW/BpCC-1	KFR-26GW/BpVE+3	KFR-35GW/BpSF-3
	KFR-26GW/BpCC-2	KFR-26GW/BpVF+3	KFR-35GW/BpSFA-2
	KFR-26GW/BpDA-2	KFR-26GW/BpVH-2	KFR-35GW/BpSFA-3
	KFR-26GW/BpDA-3	KFR-26GW/BpVMA+3	KFR-35GW/BpSFC-2
	KFR-26GW/BpDGC-2	KFR-26GW/BpZA+3	KFR-35GW/BpSFC-3
	KFR-26GW/BpDGC-3	KFR-26W/BpC+2d	KFR-35GW/BpSFD-2
	KFR-26GW/BpDMA-2	KFR-26W/BpC+2h(4)	KFR-35GW/BpSFD-3
	KFR-26GW/BpF01+3	KFR-26W/BpC-2h(3)	KFR-35GW/BpSFE-2
	KFR-26GW/BpF01A+3	KFR-26W/BpCC-1	KFR-35GW/BpSFN-2
	KFR-26GW/BpF01B+3	KFR-26W/BpD-2	KFR-35GW/BpSQ-3
	KFR-26GW/BpF02+3	KFR-26W/BpD-3	KFR-35GW/BpSQC-2
	KFR-26GW/BpF02A+3	KFR-26W/BpS-2	KFR-35GW/BpSQC-3
	KFR-26GW/BpF02B+3	KFR-26W/BpS-3	KFR-35GW/BpSS-3
	KFR-26GW/BpF02C+3	KFR-26W/BpV-2	KFR-35GW/BpSSA-3
	KFR-26GW/BpFG+3	KFR-35GW/BpCC-1	KFR-35GW/BpSSD-2
	KFR-26GW/BpKGC-2	KFR-35GW/BpCC-2	KFR-35GW/BpSSD-3
	KFR-26GW/BpKMA-2	KFR-35GW/BpDA-2	KFR-35GW/BpVB+3
	KFR-26GW/BpKMA-3	KFR-35GW/BpDA-3	KFR-35GW/BpVB-2
	KFR-26GW/BpKPA-3	KFR-35GW/BpDGC-2	KFR-35GW/BpVC+3
	KFR-26GW/BpLA+3	KFR-35GW/BpDGC-3	KFR-35GW/BpVE+3
	KFR-26GW/BpSFA-2	KFR-35GW/BpDMA-2	KFR-35GW/BpVF+3
	KFR-26GW/BpSFA-3	KFR-35GW/BpF01+3	KFR-35GW/BpVH-2
	KFR-26GW/BpSFC-2	KFR-35GW/BpF01A+3	KFR-35GW/BpVH-3
	KFR-26GW/BpSFC-3	KFR-35GW/BpF01B+3	KFR-35GW/BpVMA+3
	KFR-26GW/BpSFD-2	KFR-35GW/BpF02+3	KFR-35GW/BpZA+3
	KFR-26GW/BpSFD-3	KFR-35GW/BpF02A+3	KFR-35W/BpC+2h(4)
	KFR-26GW/BpSQC-2	KFR-35GW/BpF02B+3	KFR-35W/BpC-2h(3)
	KFR-26GW/BpSQC-3	KFR-35GW/BpF02C+3	KFR-35W/BpCC-1
	KFR-26GW/BpSSD-2	KFR-35GW/BpFG+3	KFR-35W/BpD-2
	KFR-26GW/BpSSD-3	KFR-35GW/BpKGC-2	KFR-35W/BpD-3
	KFR-26GW/BpVB+3	KFR-35GW/BpKMA-2	KFR-35W/BpS-2
	KFR-26GW/BpVB-2	KFR-35GW/BpKMA-3	KFR-35W/BpS-3
KFR-26GW/BpVC+3	KFR-35GW/BpKPA-3	KFR-35W/BpV-2	

厂家	机型	机型	机型
ODM	YORK 空调 YHJH-120A/E2AF	澳柯玛 KFR-26GW/BpAU-A3	惠康 KFR-35GW/BpK-3
	YORK 空调 YHJH-120A/E2AM	澳柯玛 KFR-26W/BpAU-A3	惠康 KFR-35GW/BpV-3
	YORK 空调 YHJH-120A/E3AF	澳柯玛 KFR-35G/BpAU05-A3	惠康 KFR-35W/BpK-3
	YORK 空调 YHJH-120A/E3AM	澳柯玛 KFR-35GW/BpAU01-K2	惠康 KFR-35W/BpV-3
	YORK 空调 YHJH-90A/E2AF	澳柯玛 KFR-35GW/BpAU02-K2	康佳 KFR-26GW/BpDK03-E3
	YORK 空调 YHJH-90A/E2AM	澳柯玛 KFR-35GW/BpAU-A3	康佳 KFR-35GW/BpDK03-E3
	YORK 空调 YHJH-90A/E3AF	澳柯玛 KFR-35W/BpAU-A3	日普 KFR-26GW/BpCFD-2
	YORK 空调 YHJH-90A/E3AM	澳柯玛 KFR-35W/BpAU-K2	日普 KFR-26W/BpCFD-2
	约克 YHJH-120A/E2AF	惠而浦 ISH-120S2A/A	日普 KFR-35GW/BpCFD-2
	约克 YHJH-120A/E2AM	惠而浦 ISH-120S3A/A	日普 KFR-35W/BpCFD-2
	约克 YHJH-120A/E3AF	惠而浦 ISH-90S2A/A	伊莱克斯 EAS26HVHCIA
	约克 YHJH-120A/E3AM	惠而浦 ISH-90S3A/A	伊莱克斯 EAS35HVHCIA
	约克 YHJH-90A/E2AF	惠康 KFR-26GW/BpK-3	伊莱克斯 EAW26VD22AB1
	约克 YHJH-90A/E2AM	惠康 KFR-26GW/BpV-3	伊莱克斯 EAW35VD22AB1
	约克 YHJH-90A/E3AF	惠康 KFR-26W/BpK-3	EAS26HVHCIA
	约克 YHJH-90A/E3AM	惠康 KFR-26W/BpV-3	EAS35HVHCIA

获取更多资料

售后通用版说明

一、使用范围

1、该控制器使用时必须配合压缩机的型号对应起来，新增的压缩机后期会升级控制器的软件，并更改说明书！

2、目前空调挂机产品使用压缩机型号包括：



DA89X1C-20FZ，对应红色拨码器为 0000



DA89M1C-30FZ；对应红色拨码器为 0001

DA98M1C-30FZ；对应红色拨码器为 0001



ASM130D12UFZ；对应红色拨码器为 0010

ASM108D12UFZ；对应红色拨码器为 0010



ASM108D13UFZ；对应红色拨码器为 0011



ASN98D-32UFZ；对应红色拨码器为 0100

ASN108D-32UFZ；对应红色拨码器为 0100

对应压缩机拨码见使用方法。

3、控制器还需要对风机进行选择，有无回气传感器进行选择。

直流风机均为白色塑壳风机，交流风机均为金属铁壳风机。回气传感器为白色三芯传感器端子。

4、压缩机选择在 K1 红色拨码开关，回气选择和风机选择在 K2 蓝色拨码开关

5、**该控制器目前不适用前期生产的四级能效机型**（压缩机为美芝 DH130）和儒竞控制器机型（压缩机为三洋 110）。

6：前期生产的铁壳控制器，压缩机为 DA89-20，可以用该拨码控制器维修替换。该类控制器多为老三级能效机型。

7：回气传感器故障为 FA,直流风机故障为 F0，模块保护故障为 F1，如拨码控制器报上述故障请再次核对整机信息。

二、使用方法

使用时请先确认压缩机型号，有无回气传感器，外风机类型

拨码定义如下：

红色 K1 拨码 1,2,3,4 共计 4 位为压机选择

序号	1	2	3	4	压缩机拨码选择
1	0	0	0	0	DA89X1C-20FZ
2	0	0	0	1	DA89M1C-30FZ/DA98M1C-30FZ
3	0	0	1	0	ASM130D12UFZ/ASM108D12UFZ
4	0	0	1	1	ASM108D13UFZ
5	0	1	0	0	ASN98D-32UFZ/ASN108D-32UFZ

蓝色拨码开关 5 和 6 两位是对应风机选择和回气温度传感器选择，最后一位暂不用


拨码 5：回气温度传感器选择

序号 5 拨码	回气传感器选择
0	有回气传感器
1	无回气传感器


拨码 6：外风机选择

序号 6 拨码	外风机选择
0	直流风机
1	交流风机

请注意：拨码号 1、2、3、4、5、6 数字是指线路板面上的白色丝印数字，不是开关上的数字



三、图例说明



回气传感器接头端子图例：

